Hearing Helper™ Personal FM Receiver • Model PFM R31







Description:

Maximize a student's ability to listen with the Personal FM R31 receiver from Williams Sound. The PFM R31 will ensure that everyone in the classroom can hear the speaker's message clearly and easily. Each receiver has a range of up to 150 feet, and will operate up to 80 continuous hours. Versatile 3.5 mm jack allows for a variety of earphone and headphone options, or, equip it with a neckloop to make it compatible with most telecoil-equipped hearing aids.

The PFM R31 features a sensitive environmental microphone which gives the listener more flexibility on what they want to hear. By turning on the environmental mic, they can listen to a nearby classmate speak more clearly.

Applications:

Controls:

Classrooms • Job Consultation • Job Training • Tours • Group Meetings

PFM R31 FM Receiver:

Dimensions: 3-5/8" L x 2-3/8" W x 7/8" H (92.1 mm x 60.3 mm x 22.2 mm)

Weight: 4.6 oz (130 g) with batteries

Color: Royal blue, shatter-resistant polypropylene

Battery Type: Two (2) AA 1.5 V non-rechargeable Alkaline batteries (BAT 001),

14 mA nom. current drain, 80 hours approx. life

(OR) Two (2) AA 1.5 V NiMH rechargeable batteries (BAT 026), 14 mA nominal current drain, 50 hours per charge approx.,

recharges in 14–16 hours, uses CHG 200 Charger Pre-tuned, field–tuneable, 72 MHz - 76 MHz*.

Operating Freq's: Pre-tuned, field-tuneable, 72 MHz - 76 MHz*. Pre-set channels are E (72.9 MHz) and G (75.7 MHz).

FM Deviation: Wide-band, 75 kHz, 75 μS de-emphasis

AFC Range: ± 120 kHz

Sensitivity: 4 μV at 12 dB Sinad with squelch defeated,

squelches at 10 μV for min. 50 dB S/N ratio

Freq Response: 100 to 10 kHz, + 3 dB

Signal-to-Noise Ratio: 50 dB at 10 uV

Receive Antenna: Integral with earphone cord

Audio Output: $\frac{35 \text{ mW, max. at } 16 \ \Omega}{3.5 \text{ mm mono phone jack}}$

Squelch: Set to turn off audio under weak or no signal condition

Carrier Detect Ind: Red LED, turns on in the presence of a carrier

Volume: Rotary, On/Off/Volume

Tone: 3-way slide switch; Lo: flat response (20 Hz), Mid: -3 dB at 235

Hz, Hi: -3 dB at 730 Hz

Channel: 2-way slide switch; Ch 1 = 72.9 MHz, Ch 2 = 75.7 MHz

Indicators: On/Off and FM

Mic Connector: 3.5 mm mono phone jack, supplies positive DC for Williams

Sound electret mics

Microphone: Plug mount electret, omnidirectional, with windscreen, 3.5 mm

mono phone plug (MIC 014)


Mic Volume: Rotary control

Note: Specifications are electrical performance


Approvals: FCC, WEEE

Warranty: 5 years, parts and labor**

*DISCLAIMER: FCC RULES LIMIT USE OF THIS EQUIPMENT TO AUDITORY ASSISTANCE FOR THE HANDICAPPED.




NOTE: SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE!



R31 Top



R31 Front



R31 Back



Hearing Helper™ Personal FM Receiver • Model PFM R31









Acoustic Specifications:

ANSI 2.44 Test





FM Response (PFM R31)

Input:	
Device:	
Y:	

X:

80 dB random noise

KEMAR mannequin w	vith BTK 3550) tester	
80.0 dB 80 db	Main Y:	34.1 dB	
100 Hz + 8 OCT LOG	Main X:	4 kHz	

Environmental Mic Response (PFM R31)

Input:	
Device:	
Y:	
٧.	

80 dB random noise KEMAR mannequin with BTK 3550 tester 80.0 dB 80 db Main Y: 50.2 dB 100 Hz + 8 OCT LOG Main X: 4 kHz

ANSI S3.22-1987 Test

FM Response (PFM R31)

Minimum Low Cut (Tone Set to Low)

Max. SSPL90: HF Avg. SSPL90: HF Avg. Full On Gain: Reference Test Gain: Response Limit:

Total Harmonic Dist:

135.8 dB at 500 Hz 127.1 dB 37.7 dB at 60 dB in 38.1 dB 80.1 dB F1=200 Hz, F2=8 kHz

3.6 % at 500 Hz $3.9\ \%$ at $800\ Hz$ 2.2 % at 1600 Hz

Maximum Low Cut (Tone Set to Hi)

Max. SSPL90: HF Avg. SSPL90: HF Avg. Full On Gain: Reference Test Gain: Response Limit:

Total Harmonic Dist:

35.8 dB 78.01 dB F1=200 Hz, F2=8 kHz 1.1 % at 500 Hz 2.7 % at 800 Hz 2.1 % at 1600 Hz

133.5 dB at 1000 Hz

35.4 dB at 60 dB in

127.0 dB

Medium Low Cut (Tone Set to Mid)

Max. SSPL90: HF Avg. SSPL90: HF Avg. Full On Gain: Reference Test Gain: Response Limit:

Total Harmonic Dist:

135.5 dB at 600 Hz 127.1 dB 36.8 dB at 60 dB in 37.3 dB 79.4 dB F1=200 Hz, F2=8 kHz 3.4 % at 500 Hz

3.4 % at 800 Hz 2.2 % at 1600 Hz

Environmental Mic Response (PFM R31)

No Tone Modification

Max. SSPL90: HF Avg. SSPL90: HF Avg. Full On Gain: Reference Test Gain: Response Limit:

Total Harmonic Dist:

134.8 dB at 500 Hz 126.4 dB

40.9 dB at 60 dB in 40.8 dB 81.1 dB

F1=200 Hz, F2=8 kHz 1.1 % at 500 Hz

1.1 % at 800 Hz 0.3 % at 1600 Hz

NOTE: SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE!



Hearing Helper™ Personal FM Receiver • Model PFM R31







Bid Specs:

Not Currently Available

Contact:

United States

Williams Sound Corp. 10321 W. 70th Street Eden Prairie, MN 55344-3446

Ph: 800-328-6190 / 952-943-2252 / FAX: 952-943-2174

Email: info@williamssound.com Web: www.williamssound.com

Canada

Thorvin Electronics 2861 Sherwood Heights Dr. Units 36-37 Oakville, ON L6J-7K1 Canada

Ph: 800-323-6634 / 905-829-3040 / FAX: 905-829-4196

Web: www.thorvinelectronics.com

Asia, Australia, Latin America, Middle East, South Africa

International Sales Department Williams Sound Corp. 10321 W. 70th Street Eden Prairie, MN 55344 USA

Phone: +1 952 224 7791 Fax: +1 952 943 2174

Email: info@williamssound.com Web: www.williamssound.com

NOTE: SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE!

